## MAILBOX REQUIREMENTS

## Notice

<u>BEFORE</u> installing/constructing your mailbox, you must call the U.S. Post Office, North Shore Station, at 267-1637 and talk to the Post Master. They will assign the location of your mailbox.

## **INSTRUCTIONS**

Whenever possible, boxes must be located so that carrier's vehicle is off pavement when serving them.

Box number must be on box in numerals not less than one inch high.

Post must be neat and of adequate strength and size.

Approach to box should be a hard level surface, (gravel, cinders, stone).

Boxes must be placed to conform with state laws and highway regulations.

Suggested installation

Suggested installation where snow removal is

of a single box.

a problem.

Extend box beyond end of post. Attach board holding box to post with screws or doublehead nails, permitting easy removal if necessary to adjust box height.

38 - 41 inches